Step-by-Step Instructions

(PRINT this set of instructions to follow every time you refill your cartridge)

Brother LC75 Black/Cyan/Magenta/Yellow
Refillable Cartridges

Unplug, Fill, Re-plug

Items needed: gloves, Black Dye, Cyan, Magenta, Yellow inks, paper towels, review hints & tips and check list.

1) Remove the cartridge when it is running low or out of ink.

2) Place the cartridge down with the plug facing up. Remove both the filling hole plug and the vent hole plug. The clear flat plug on the top of the cartridge is your fill hole. The color plug on the top of the cartridge is your vent hole plug. Remove both the filling hole plug and the vent hole plug.

3) Release through your needle tip the proper color ink. The black cartridge will take black dye ink and up to approximately 30 mls of ink. All colors will take up to approximately 20 mls of ink.

The black cartridge will take up to approximately 35mls

The color cartridges will take up to approximately 20mls

4) Put the syringe needle into the fill hole and S-l-o-w-l-y inject ink, leaving a small air space at the top of the cartridge. The cartridges are transparent so it easy to see the cartridge filling up.

5) After the cartridge is full of ink, seal the fill hole with the clear flat plug.

6) Leave the Vent Hole Plug out if you are going to put the cartridge into the printer. If you are going to save the filled cartridge for use at a later date then put the Vent Hole Plug back in. The Vent Hole Plug is only used for storing the cartridge for later use. When putting the cartridge into the printer be sure to remove the Vent Hole Plug. If you don't do this, the cartridge will not print.

7) Replace the cartridge(s) and run 1 - 3 cleaning cycles as per printer instructions.
   Or print the following pages:
   http://www.inkonline.net/support/colorinktest Color Ink Test
   http://www.inkonline.net/support/blackinktest   Black ink test