



Step-by-Step Instructions

(PRINT this set of instructions to follow every time you refill your cartridge)

KODAK



NOTE: You will need to replace the chip on the cartridge with the chips you purchased from us. Make a mental note of the copper strip positions on the chip and how it sits in the chip slot. Draw a picture for yourself. Notice the copper strip on the left hangs lower than the copper strip on the right. With your finger nail gently hold back the tiny clip keeping the chip in place. Slide the old original chip up and out of the slots holding it in place and slide the new chip back in its place. Make sure the left copper strip is hanging lower than the copper strip on the right. The chip with the black background is for your black cartridge. The chip with the green background is for your color cartridge.

Kodak Printer Ink Cartridges (One Color)

In Kodak printer ink cartridges the ink is retained due to the presence of internal sponge in the cartridge. The following steps can be used for the easy refilling of these cartridges.

1. Spread some absorbent material like a newspaper or a towel in order to avoid a mess.
2. Create a hole in the top lower flat surface using a drill or a heated pin. Drill a hole $1/3^{\text{rd}}$ of the way from the edge. Make the hole where the letter 'K' is written.
3. Fill $\frac{1}{2}$ of the syringe bottle with ink about 10 to 15ml.
4. Insert the needle into the cartridge and inject slowly into the sponge. Inject deeply so that the sponge gets saturated.



5. You can reseal the hole but it is not necessary.

6. Expect some dripping but for greater results leave the cartridge overnight. Seal it if you have to transport it.

Kodak Printer Ink Cartridges (Colored & Photo Cartridge)

The colors of ink used in these cartridges are:

- Red (or magenta)
- Blue (or cyan)
- Yellow

The first step for refilling remains the same:

1. First the lid has to be removed. This can be done with a sharp knife at the intersection of colored and black plastic. Remove the lid.

2. Insert a pin or toothpick into each hole in order to check the different colors in chambers.

3. Fill the syringe bottle about 1/8th with ink which is 5ml for each chamber.

4. Insert the needle into the cartridge and slowly inject so that the internal sponge gets saturated. All colors may not empty fully so the sponge will not soak fully.

5. Repeat the 2nd and 3rd step for the other two colors and fill the chambers with different syringes.

6. Place the cap back on top and tape it.

7. Expect some dripping but for greater results leave it overnight.

6. Run 1 - 3 cleaning cycles as per printer instructions.

Or print the following pages:

http://www.freeink4life.com/black_print_test.html

http://www.freeink4life.com/color_print_test.html

AccuBrite, Inc. is not affiliated with the listed printer manufacturers or their subsidiaries. The use by AccuBrite, Inc. does not imply endorsement by or association with the brand name owners. The listed manufacturers, printers and cartridges are used only for the purpose of showing the compatibility of this AccuBrite, Inc. product. All other trademarks, brand names and logos referenced in or on this product are the property of their respective owners. This material is protected by the copyright laws of the United States and other countries. It is illegal to reproduce these instructions. It may not be reproduced, distributed, or altered in any fashion by any entity (either internal or external to AccuBrite), except in accordance with applicable agreements or contracts of licensing, without the express written consent of AccuBrite, Inc.