


# Step-by-Step Instructions

(PRINT this set of instructions, to follow every time you refill your cartridge)

Epson T001011

EPSON STYLUS PHOTO/PHOTO EX/700



Items needed: cyan, photo cyan, magenta, photo magenta, and yellow inks, paper towels, gloves, aluminum circle tape, refill station # 2, Review hints & tips and check list.

**Syringe:** Attach needle tip (located inside station # 4) to the syringe tightly. Unscrew lid on ink bottle. Puncture silver seal with needle tip making a small hole in the center of seal. Pull the correct amount of ink into the syringe. Rinse syringe and needle tip after every use and before using syringe with another color. Rinse syringe and needle tip with water until the water runs clear.

## Cartridge Logic

The ink in this cartridge is retained because the cartridge has an internal sponge.

For best results, never leave your Epson printer without an installed cartridge -- even an empty one -- for more than an hour or so, because the ink -- the original or our refill ink -- will begin to gel to the consistency of honey, which will require multiple cleaning routines to clear.

**The most likely problem is that you have an air bubble in the exit tube of your cartridge. Remember that the absence of ink is the same as an air bubble. You can confirm that this is the problem if the printhead cleaning routine actually makes the problem worse.**

**What is happening is that a small air bubble expands under the vacuum of printing to form a large air bubble, which blocks the flow of ink to the printhead. This problem usually occurs after printing 1 or 2 good pages.**

**To clear the problem, you may wish to let the printer sit without printing for several minutes, while tapping on the top of the cartridge. This may get the air bubble to move to the top of the cartridge. It may not. If necessary leave cartridge in printer for up to 3 hours. This allows the ink to flow to the bottom of the cartridge.**

**Another idea is to remove the cartridge and try again. Also, try putting a single drop of ink directly into the point where the cartridge is plugged into. But be very careful not to spill the ink!**

## Photo Color Cartridge

1. Put the cartridge on some paper towels inside station # 2 in an area where you can tolerate a spill.
  2. Locate the 5 black rubber seal(s) on the bottom of the cartridge.
  3. Place Tape over each of the outlet hole(s) in the base of the cartridge. A separate piece over each hole is preferred.
  4. Insert the correct color thru the syringe inside of each of the 5-fill-holes. A little ink might come out of the top when full, so cover up the other holes while filling one. S-l-o-w-l-y release thru the syringe 10 ml of ink into each of the five fill-holes. If ink begins to "bubble" out of the fill-hole, remove bottle tip. Bubbling occurs when a cartridge is either over-filled or if ink is being inserted too quickly. Wait several minutes and then try to s-l-o-w-l-y insert more ink. If ink begins to bubble out the fill hole or leak from the printhead, you have plenty of ink in the cartridge.
  5. Push needle through the label all the way into the cartridge of the proper filling hole. (You can check each hole with a toothpick if you are not certain of which color goes into each hole) Inject ink very slowly into the sponge until the cartridge is full. (This will soak the sponge with ink and refill the reservoir).
- From left to right the inks wells are 1 to 5:**
1. Regular cyan (blue)
  2. Photo Cyan (blue)
  3. Regular Magenta (red)
  4. Photo Magenta (red)
  5. Regular Yellow

6. Use the flat aluminum plugs-adhesive tape to seal the hole(s) made in the top label.  
**Note: The cartridge will leak if the holes are not sealed properly.**

7. **Important** - Next, remove the tape from all exit ports.

8. Reinsert the cartridge and run 1 - 3 cleaning cycles as per printer instructions. Or print 2 pages at this test site:

<http://www.inkonline.net/support/colorinktest>    Color Ink Test

<http://www.inkonline.net/support/blackinktest>    Black ink test

For best results, leave cartridge in printer for 8 hours after refilling so the ink can saturate the entire sponge to allow ink to flow to the print head.

**NOTE: This time is reduced if cartridge is refilled before it is completely empty.**

AccuBrite, Inc. is not affiliated with the listed printer manufacturers or their subsidiaries. The use by AccuBrite, Inc. does not imply endorsement by or association with the brand name owners. The listed manufacturers, printers and cartridges are used only for the purpose of showing the compatibility of this AccuBrite, Inc. product. All other trademarks, brand names and logos referenced in or on this product are the property of their respective owners. This material is protected by the copyright laws of the United States and other countries. It is illegal to reproduce these instructions. It may not be reproduced, distributed, or altered in any fashion by any entity (either internal or external to AccuBrite), except in accordance with applicable agreements or contracts of licensing, without the express written consent of AccuBrite, Inc.

Copyright © AccuBrite, Inc. 2003-2008. All rights reserved